



StringA-Level™ System





Designed to be used for any wall tile installation where tiling begins at the floor.

Reusable tool that eliminates wasted time to determine levelness of tiles and wood stringers.

Maintains accuracy and levelness.





Flexible Sections:

13" long with 4- living hinges for inside and outside corners.

Level vial set in each end to maintain level around corners.

Can be attached to additional flexible or rigid sections.

Five slots for attaching to a wall.

Molded yellow plastic

Size: 13 -15/16" L X 1- 1/4" W X 2" H





Rigid Sections:

27" long; has a single level vial in center.

Can be attached to another rigid section

Four slots for attaching to a wall.

Molded red plastic.

Size: 27" L X 1- 1/4" W X 2" H





Inside and outside cornering

Curved Walls





Virtually any configuration.





Begin StringA- Level™ Layout





After Layout; Begin to attach to the wall





Add rigid pieces





Use screws and washers when attaching the flexible or rigid pieces





Installing the StringA- Level™ System





Completed StringA- Level™ System Layout





Completed StringA- Level™ System Layout with Kirb-Perfect™ and Quick Pitch®





Begin by stacking the tile





Finish bottom course





After tile sets, remove StringA-Level™





Scrape off setting material





Sponge clean





Perfect showers...Perfect pitches...

